


Модели QuickScan Lite QW2100	
QuickScan Lite Imager, Black, KBW/RS-232 Interface	QW2170-BK
QuickScan Lite Imager, Black, KBW/RS-232 Interface (Sold in increments of 10.)	QW2170-BK-10
QuickScan Lite Imager, Black, KBW/RS-232 Interface w/ KBW Cable (90G001010)	QW2170-BKK3
QuickScan Lite Imager, Black, KBW/RS-232 Interface w/ KBW Cable (90G001010) Sold in increments of 10.	QW2170-BKK3-10
QuickScan Lite Imager, Black, KBW/RS-232 Interface w/ KBW Cable (90G001010) and Stand (STD-QW20-BK)	QW2170-BKK3S
QuickScan Lite Imager, Black, KBW/RS-232 Interface w/ KBW Cable (90G001010) and Stand (STD-QW20-BK) Sold in increments of 10.	QW2170-BKK3S-10
QuickScan Lite Imager, Black, USB Interface	QW2120-BK
QuickScan Lite Imager, Black, USB Interface (Sold in increments of 10.)	QW2120-BK-10
QuickScan Lite Imager, Black, USB Interface w/ Enhanced USB Cable (90A052065) and Stand (STD-QW20-BK) Sold in increments of 10.	QW2120-BKK12S-10
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052043) and Stand (STD-QW20-BK)	QW2120-BKK11S
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052044)	QW2120-BKK1
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052044) Sold in increments of 10.	QW2120-BKK1-10
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052044) and Stand (STD-QW20-BK)	QW2120-BKK1S
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052044) and Stand (STD-QW20-BK) Sold in increments of 10.	QW2120-BKK1S-10
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052065)	QW2120-BKK12
QuickScan Lite Imager, Black, USB Interface w/ USB Cable (90A052065) and Stand (STD-QW20-BK)D	QW2120-BKK12S
QuickScan Lite Imager, Black, USB Interface with USB Cable (90A052043)	QW2120-BKK11
КАБЕЛИ	
Cable, IBM AT/XT, KBW, Din Connector, Straight, CAB-322, 7 ft.	90G001020
Cable, IBM PS/2, KBW, Minidin Connector, Coiled, CAB-365, 6 ft.	90A051360
Cable, RS-232, 25P, Female, Straight, CAB-328 (Power Supply available on pin 9 of the connector or with external power supply), 2 Meters	90G001080
Cable, RS-232, 25P, Male, Coiled, CAB-364 (Power Supply available on pin 9 of the connector or through external power supply), 6.5 ft.	90A051350
Cable, RS-232, 9P, Female, Coiled, CAB-408 (Power available on pin 9 of the connector or through external power supply), 6 ft.	90A051891
Cable, RS-232, 9P, Female, Straight, CAB-327, Requires External Power, 6 ft.	90G000008
Cable, RS-232, 9P, Male, Beetle POS, Straight, CAB-389, Power Off Terminal, 6.5 ft.	90A051710
Cable, RS-232,6' (For Magellan)	90G001092
Cable, USB, IBM PowerPlus Mode, Straight CAB-413, 6 ft.	90A051903
Cable, USB, Type A, Coiled, 9', CAB-424E	90A052043
Cable, USB, Type A, Coiled, Power off terminal, 2 Meters, CAB-424E	90A052100
Cable, USB, Type A, Enhanced, Straight, Power Off Terminal, 2M (USB Certified)	90A052065
Cable, USB, Type A, Straight, 6', CAB-426E (USB Certified)	90A052044

ДОПОЛНИТЕЛЬНОЕ ОБОРУДОВАНИЕ		
	Черный стенд/Держатель	STD-QW20-BK
POWER SUPPLIES/CORDS		
Adapter, Power Plug, Australia (Use with 4004-0849)	6003-0939	
Adapter, Power Plug, Euro (Use with 4004-0849)	6003-0937	
Adapter, Power Plug, UK (Use with 4004-0849)	6003-0938	
Adapter, Power Plug, US/Japan (Use with 4004-0849)	6003-0936	
Power Cord, 2-Pin, EU	90ACC1885	
Power Cord, 2-Pin, UK	90ACC1887	
Power Cord, 2-Pin, US	90ACC1886	
Power Supply, 5VDC, ROHS (Power Adapter Sold Separately.)	4004-0849	